

Kit



# FRP Motor Seals Kit

---

407038A  
EN

For repairing the seals in the FRP motor.



## **Important Safety Instructions**


Read all warnings and instructions in FRP system manual. **Save all instructions.**

Part No. 16N238

---

PROVEN QUALITY. LEADING TECHNOLOGY.

# Parts



ti18470a

 Apply lubricant.

| Ref | Part | Description                     | Qty |
|-----|------|---------------------------------|-----|
| 2   | ---  | SEAL, rod, h-wiper,<br>1.000 ID | 2   |
| 4   | ---  | SEAL, u-cup, 1.0 in             | 2   |
| 5   | ---  | RING, retaining                 | 2   |
| 7   | ---  | PACKING, o-ring                 | 2   |
| 11  | ---  | PACKING, o-ring                 | 1   |
| 18  | ---  | GASKET, manifold,<br>medium     | 2   |
| 20  | ---  | GASKET, air valve,<br>medium    | 1   |

--- Not for sale

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

For patent information, see [www.graco.com/patents](http://www.graco.com/patents).

Original Instructions. This manual contains English. MM 407038

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**

**Copyright 2012, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)